

# Genesis™



## SOLAR COMFORT RADIANT ENERGY BARRIER INSTALLATION INSTRUCTIONS FOR STATIONARY PANELS

Thank you for choosing Genesis Solar Comfort Stationary Panels. With proper installation and care, your new shades will provide many years of beauty and performance.

**Caution:** Handle material with care as this is a perforated film, not a soft fabric. Clear tape is adhered to the side edges in order to prevent the rough perforated edges from snagging objects. A pair of cotton gloves will be sent with each order to handle the material. Slight creases will definitely become less noticeable at the window by gently rubbing the material in an outward motion.

### Installation Options

Top of Panel - A white "L" Angle with white velcro hook on the front that allows a ceiling or casing mount  
OR an Aluminum Flat Track with white velcro hook on the front

Bottom of Panel - A Free Hanging Hem using the contoured aluminum hem bar  
OR a white "L" Angle with white velcro hook on the on the front that allows a ceiling or casing mount  
OR an Aluminum Flat Track with white velcro hook on the front

**White L Angle with White Hook** - Screws will be drilled directly through the PVC with the velcro facing room side. Go in 2" from each end and then approximately every 30" for screw placement.

**Aluminum Flat Track** - Use screws provided. Go in 2" from each end and then approximately every 30" for bracket placement.

### Tools and Fasteners Needed

Power Drill, 1/4" Driver and drill bits  
Tape Measure  
Flat blade Screwdriver  
Phillips Screwdriver  
Pencil  
Level

