



LOUVER INSTALLATION FOR PLANTATION AND TRADITIONAL SHUTTERS

Tools required: Metal putty knife (with sharpened edge)
Hammer (plastic mallet preferred)
Offset needlenose pliers
Utility knife
Louver pin with washer (1) #12-0300-000
Replacement pin (1) 12-0307-000

- 1) Remove the existing louver if necessary.
- 2) Insert the louver pin with washer (12-0300-000) into one end of the louver.
- 3) Tilt the louvers in the panel to the open position. Slide the new louver between the stiles inserting the pinned end into the louver pin hole.
- 4) Place new springd-loaded pin (12-0307-00) into vacant hole.
- 5) Using the tip of the utility knife blade, depress the pin against the spring until it recesses into the hole in the stile.
- 6) Slide the louver over the pin and pull the utility knife from between the louver and the pin.
- 7) Slowly move the louver across the pin until the pin pops into the louver hole.
- 8) Spin the louver in both directions to insure that the pin has seated into the louver properly.
- 9) Connect the louver to the tilt rod (see: Staple Replacement)

